

Quick Start Guide



Lifesize® Phone™ HD


With Lifesize® Phone™ HD, you can manage audio, web and video conferencing, as well as share your screen, making it easier than ever to collaborate with colleagues and partners. The vivid and responsive touchscreen interface provides rapid access to the most popular features. Let's get started!




For Lifesize customers with Lifesize Phone HD attached to a Lifesize® Icon™ (excluding Lifesize Icon Flex), you can customize your Lifesize Phone HD home screen with the buttons and time zones that work best for you. [Learn how](#)

Make A Call


1. From the Home Screen, tap the **Call** icon.




2. Now tap the **Directory** icon.



3. Select the person to call.




4. Select **Dial as Video** or **Dial as Voice**.



QUICK TIPS: Locate and add contacts using **Recents**, **Directory**, or **Favorites**. Join a meeting using **Meetings**. Use the **Keypad** to dial a phone directly.

Mute Audio


While in a call, tap the **Mute Audio** icon.



DID YOU KNOW? The lights on Lifesize Phone HD will turn red when audio is muted..

End a Call


Tap the **End** icon.



DID YOU KNOW? There are several ways to end a call. You can remove yourself or one or more of the participants on the call

Adjust Volume


While in a call, tap the **Volume** icon. Adjust volume with slider.



QUICK TIP: To adjust the volume before starting a call, tap the Start icon on the Home Screen to access the Volume icon.

Start a Presentation

While in a call, tap the **Present** icon.




QUICK TIP: While in a call, tap the **Layouts** icon for screen layout options. To end presentation mode, just tap the **Presenting** icon.

DID YOU KNOW? You can share your screen whether you're in a video call or giving a presentation to others in the conference room.

Mute Video

1. While in a call, tap the **More** icon.


2. Tap the **Mute Video** icon.



Move the Camera

1. While in a call, swipe left and tap the **Camera** icon.

2. Reposition/zoom camera using the controls.



QUICK TIP: If you'd like to move the camera before you make a call, just tap the **Camera** icon on the Home Screen.


DID YOU KNOW? You can add a preset by pressing and holding a number in the **Presets** bar.

QUICK TIP: When you are in a one-on-one call, you can move their camera. Just look for the **Remote** icon.

Enable Do Not Disturb

1. While in a call, tap the **More** icon.


2. Tap the **Do Not Disturb** icon.



Record a Call

1. While in a call, tap the **Record** icon.

2. Select the person to own the recording.



NOTE: Lifesize Record and Share is required to be able to record a call.

HEADQUARTERS
Austin, Texas, USA
+1 512 347 9300
Toll Free US +1 877 543 3749

EMEA REGIONAL OFFICE
London
+44 207 5962 835

APAC REGIONAL OFFICE
Singapore
+65 6631 2831



www.lifesize.com
E-mail: info@lifesize.com



©2018 Lifesize, Inc. All rights reserved. Information contained in this document is subject to change without notice. Lifesize and the Lifesize logo are registered trademarks of Lifesize, Inc. All other trademarks are the property of their respective owners.

QSG_PhoneHD_US_0218